

## Floodtite Airbrick Cover

The following items are included with your Floodtite Airbrick Cover and will be required for fitting:

**Single Airbrick Cover:** 2 anchor plugs; 2 T-handle screws;  
2 anti-loss washers (to keep T-handle screws attached to Airbrick Cover)

**Double Airbrick Cover:** 4 anchor plugs; 4 T-handle screws; 4 anti-loss washers

**Please check you have received these items and phone 0208 442 0872 with any discrepancies.**

### Tool requirements

- Power drill; 7mm masonry Bit; Hammer; 4mm Parallel Pin Punch (or Phillips screwdriver).

### Fitting the wall fixings

- Using the airbrick cover as a template, mark securing holes on the brickwork.
- Drill each hole to a depth of 25mm using a 7mm masonry Bit.
- Insert anchor plug (supplied) into each hole until flush with brickwork.
- Place a 4mm parallel pin punch (or similar size Phillips screwdriver) inside anchor plug and strike with a hammer to push the centre wedge into a lock position.
- Attach the T-handle screws (supplied) to the Cover and secure with anti-loss washers (supplied).
- Position T-handle screws into the anchor plugs to check fitting. It is a good idea to practise installing the Airbrick Cover on a calm dry day to ensure you are familiar with its use, so that when you install it for a flood it is not your first time doing so.
- Remove Airbrick Cover and store, with T-handle screws and anti-loss washers attached, in a cool dry place that is easily accessible in case of flood alert

### Fitting the Airbrick Cover – IN TIME OF FLOOD ALERT

- Refer to accompanying laminated instructions and **keep those instructions with the product.**

### Technical help

- Technical helpline 07712 185240
- email [tech@floodtite.com](mailto:tech@floodtite.com)